

Click on a link
tab to jump to
that page

Cover
Page

Before
You Begin

Remove
& Install

Wire
New Radio

Mount
New Radio

Publication, Duplication, or Retransmission Of This Document Not Expressly Authorized In Writing By The Install Doctor Is Prohibited. Protected By U.S. Copyright Laws. © 1997,1998,1999,2000.

Factory Radio



Other Documents Available For This Vehicle:

No additional documents available at this time

New Radio ('DIN' and Shafted)

'DIN' Radio



Adobe Acrobat Reader Printing Tips:

- 1) Select "**FILE**" then "**PRINT**" and select your printer.
- 2) In the print options box do the following:
 - A) Locate check box "**Shrink to Fit**". Place check in box.
 - B) Locate box "**Print Quality**". Select highest print dpi allowed by printer.
 - C) If print quality listed is not as high as that printers normal quality, press the "**SETUP..**" button. In the next screen, press the "**PROPERTIES**" button and set the printers print quality to the highest print dpi allowed.

Document Revision History

09/99 Document Creation

'Shafted' Radio



Click on a link
tab to jump to
that page

Cover
Page

Before
You Begin

Remove
& Install

Wire
New Radio

Mount
New Radio

Publication, Duplication, or Retransmission Of This Document Not Expressly Authorized In Writing By The Install Doctor Is Prohibited. Protected By U.S. Copyright Laws. © 1997,1998,1999,2000.

Overview Of This Radio Install

Step	What Section To Go To
Remove old radio from dash	Remove & Install
Wire the new radio	Wire New Radio
Mount the new radio	Mount New Radio
Finishing the installation	Remove & Install




Parts Needed For This Radio Install

Parts REQUIRED for the install	Description
Snap on in dash wire harness	Ford (1996 and newer) 2 pc Wire Harness

Optional parts for this install

"Shafted" radios need a radio installation kit for 'DIN' dash openings

Tools Needed To Complete This Install



TOOL TIPS:

Small Battery: use a battery to test speaker wires. Touching the (+) positive and (-) negative battery leads to a pair of speaker will cause the speaker to make a "Pop" sound indicating that pair of wires goes to that speaker.
Voltage Meter: Always check +12 Volt power wires for voltage before making wire connections. These wires will fluctuate between 10 and 14 Volts.
Solder Iron or Crimp Tool: make wire to wire connections using either a solder iron and electrical tape, OR plastic crimp terminals found at most hardware or auto parts stores.

Hand tools needed
to remove radio

Accessory tools needed to test and
wire the new radio

PLUS: Wire ties or electrical tape: to neatly bundle and organize your wires for a professional appearance.

Installation Difficulty Ratings

Easy. No advanced skills or specialty tools needed.

Basics. Simple tools required. Installs quickly.

Intermediate. Requires knowledge of tools, or disassembly of panels.

Advanced. Requires advanced tools, or extra time.

Difficult. Involves modifying or cutting of the installation area. Advanced tools and/or skills required. Best if performed by experienced installers.

Do It Yourselfers

Basics

Professional Installer

Basics

Support Information If You Need Help

Supplemental information if you need help

Document Title	Document #
Basic DC electronics for automotive applications	999001
Wire splicing: soldering vs. crimping	999004
Why use radio installation kits	999005
Mounting your radio to an installation kit	999007
Why use an optional snap on wire harness	999008
Wiring your new radio using a wire harness	999009
Testing wires when installing a new radio	999013

Click on a link
tab to jump to
that page

Cover
Page

Before
You Begin

Remove
& Install

Wire
New Radio

Mount
New Radio

Publication, Duplication, or Retransmission Of This Document Not Expressly Authorized In Writing By The Install Doctor Is Prohibited. Protected By U.S. Copyright Laws. © 1997,1998,1999,2000.

► Remove Factory Radio



STEP 1:

The Ford radio is snapped into the vehicles dash. With the proper tool, known as Ford radio removal keys, the Ford radio can be pulled forward out of the dash. A clothes hanger can be used instead of actual Ford radio removal keys. Cut the clothes hanger and bend 2 pieces in the shape as shown in the photos above. For more information on how to remove the radio, see the diagram below.




STEP 2:


Pull the radio from the dash. Unplug the antenna cable from the rear of the radio. Unplug the 2 wire harness connectors from the rear of the radio.

Removing Ford Radios Using "U" Shaped Removal Keys

Insert the "U" shaped keys into the holes as shown in the diagram. Coat hangers can be cut and bent into shape for a quick, cheap replacement or alternative when Ford keys are not available.



In order for the radio to be removed, clips attached to the side of the radio must be moved inward so the radio can slide out of the dash. Insert the keys and push each key out, away from the radio. The ends of the keys will press into the clips. While pushing the keys outward, pull and the radio should slide forward out of the dash.



Click on a link
tab to jump to
that page

Cover
Page

Before
You Begin

Remove
& Install

Wire
New Radio

Mount
New Radio

Publication, Duplication, or Retransmission Of This Document Not Expressly Authorized In Writing By The Install Doctor Is Prohibited. Protected By U.S. Copyright Laws. © 1997,1998,1999,2000.

▶ Wiring The New Radio

Move to: [Wire New Radio Section](#)

▶ Mounting The Radio

Move to: [Mounting New Radio Section](#)

▶ Completing The Radio Installation

Shafted Radios



STEP 1:


For shafted radios: mount the shafted radio to the installation kit. Attach the antenna cable to the radio. Make sure the power and speaker wires have been wired and all connectors are plugged in



STEP 2:

Once the radio and kit have been installed and secured into the dash, attach the radios face plate and attach the radios knobs.

'DIN' Radios



STEP 1:

For 'DIN' radios: slide the 'DIN' sleeve into the hole in the vehicles dash. Secure the sleeve by bending the tabs on the sleeve behind the plastic of the dash.



STEP 2:

Attach the antenna cable to the radio. Make sure the power and speaker wires have been wired and all connectors are plugged in. Slide the radio into the 'DIN' sleeve.

The Installation Is Now Complete

Click on a link
tab to jump to
that page

Cover
Page

Before
You Begin

Remove
& Install

Wire
New Radio



Mount
New Radio

Publication, Duplication, or Retransmission Of This Document Not Expressly Authorized In Writing By The Install Doctor Is Prohibited. Protected By U.S. Copyright Laws. © 1997,1998,1999,2000.



► **Step By Step Wiring**

Page 1 of 2

Auto Makers
Factory
Radio



Wire Harness Inside Vehicles
Dash Which Plugs Into The
Rear Of The Factory Radio



Optional (STRONGLY
RECOMMENDED) Snap On Wire
Harness That Splices Into The
Wires Of The New Radio


(Note: the radio shown is for display purposes and may not be similar in size or dimensions than the auto makers factory radio in your vehicle)

Supplemental information if you need help

Document Title	Document #
Testing wires when installing a new radio	999013
Why use an OEM snap on wire harness	999008
Wiring your new radio using a wire harness	999009
Wire splicing: soldering vs. crimping	999004


Wiring Instructions:

The power and speaker wires needed to connect the new radio are attached to the connector of the wire harness located inside the vehicles dash. The Install Doctor **STRONGLY** recommends using an optional snap on wire harness that is specifically designed to snap into the vehicles dash wire harness connector. This will keep you from cutting the vehicles wires. This optional snap on wire harness will have wires on the opposite side of the connector that will allow you to splice these wires to the new radios wires. The only other option is to cut off the vehicles dash wire harness connector and splice the new radios wires directly to these wires. The optional snap on wire harness takes all the guess work out of trying to figure out what each wire is in the vehicles dash wire harness. The optional snap on wire harness shows you what each wire is.



▶ Radio Wire & Color Code Information

This vehicle uses has a 2 pc wire harness.



Pin	What It Is	Typical Ford In Dash Wire Color	"Typical" New Radio Equivalent Wire Color
A	Right Rear Spkr (-)	Blue	Purple w/ Black Stripe
B	Right Rear Spkr (+)	White w/ Blue Stripe	Purple
C	Right Front Spkr (-)	White	Gray w/ Black Stripe
D	Right Front Spkr (+)	Blue w/ White Stripe	Gray
E	Left Rear Spkr (-)	Red w/ Blue Stripe	Green w/ Black Stripe
F	Left Rear Spkr (+)	White w/ Blue Stripe	Green
G	Left Front Spkr (-)	Blue w/ Orange Stripe	White w/ Black Stripe
H	Left Front Spkr (+)	Purple	White
I	Amplifier Turn On	Do Not Use For This Vehicle	
J	Power Antenna Turn On	Do Not Use For This Vehicle	
K	Ground Wire	Black	Black
L		Do Not Use For This Vehicle	
M	Dash Light Dimmer Wire		Orange (if available)
N	+12 Volt Ignition Wire	Blue w/ Black Stripe	Red
O		Do Not Use For This Vehicle	
P	+12 Volt Battery Wire	Blue w/ Red Stripe	Yellow

Note: using an optional snap on wire harness adapter will simplify the wiring. Most snap on wire harness adapters have already converted and color coded the wires from the auto makers in dash wire harness to match typical aftermarket radio wire colors.

** The wire colors listed in the chart above are typical for Ford vehicles during these years but may not be the exact colors for this vehicle. This is another reason to use a snap on wire harness adapter. **

Click on a link
tab to jump to
that page

Cover
Page

Before
You Begin

Remove
& Install

Wire
New Radio

Mount
New Radio

Publication, Duplication, or Retransmission Of This Document Not Expressly Authorized In Writing By The Install Doctor Is Prohibited. Protected By U.S. Copyright Laws. © 1997,1998,1999,2000.

▶ Mounting A Radio




NOTE:


This vehicle does not require using a dash installation kit to mount a 'DIN' style radio. If you are installing a shafted radio, you will need a radio installation kit that converts the rectangular opening to mount the shafted radio.

All information needed to complete the mounting of the new radio to the vehicles dash is included on this sheet. If you need additional help, please consult the following tech documents:

Document Title	Document #
Why use radio installation kits	999005
Mounting your radio to an installation kit	999007
Radio security	999010
'DIN' vs. Shafted radio - differences with	999006



When 'DIN' cage is inserted into the 'DIN' rectangular opening in the dash, bend these tabs behind the opening in the dash to secure the 'DIN' cage to the dash.



New radios 'DIN' cage slid into the 'DIN' opening of the dash with its tabs bent securing the cage to the dash.

The radio can now be slid into the 'DIN' cage which will snap to the radio securing the radio in place.